

Instructions for Waist Pack, Shoulder Bag, Crossbody Sling #'s 84021, 84023, 84121, and 84123

1. Zipper Security: There is a swivel clip on a leash that is sewn into the back of the bag. It is designed to extend to the front and attach to the zipper pull tabs to keep the zippers secure. When not in use this can be inserted into the sleeve on the back to keep it out of the way.
2. Setup the Strap:
 - a. Adjust the strap to your waist size, or longer to wear on your shoulder or as a sling. (pushing the strap through the adjuster buckle, rather than pulling, works best).
 - b. Insert the "box" part of the buckle into the sleeve on the back of the bag, in either direction, with the back of the strap (has a sewn-on swivel clip) facing the sleeve.
 - c. Push it through the sleeve until the "box" part of the buckle appears.
 - d. Attach the swivel clip on the long leash to the adjacent O-ring, keeping the bag and strap attached.
 - e. Fasten the buckle (prong part into rectangular box part) and it is ready to wear!
3. To Conceal the Buckle:
 - a. Slide the fastened buckle into the sleeve.
 - b. For added security, slide the buckle into the sleeve until the second swivel clip on the back of the strap appears. Fasten this swivel clip to the adjacent O-ring. This keeps the buckle securely enclosed inside the sleeve.

Feel free to call or email with questions or suggestions:

Billy Norris Owner / Designer

Ph 805-937-9160; Cell 805-406-2312

email: daymakers@daymakers.com

website: <https://daymakers.com>